



10 ~ 20 radius is recommended for chamfering for openings using stone and wood.